| DSD-201 Endoscope Reprocessor Diagnostic Functions | | | |
|---|---|---|---|
| 51 | Activate sheath valve | 76 | --not used-- |
| 52 | Activate leak test compressor valve | 77 | --not used-- |
| 53 | Activate leak test compressor | 78 | --not used-- |
| 54 | Turn off all valves and reset latches | 79 | --not used-- |
| 55 | Turn off compressor | 80 | Set language |
| 56 | Activate sheath test | 81 | Set time limit |
| 57 | Activate sheath hold | 82 | Set serial number |
| 58 | --not used-- | 83 | Programme low flash |
| 59 | --not used-- | 84 | Programme high flash |
| 60 | Set default programme | 85 | Programme entire flash |
| 61 | Set drain time | 86 | Initialize NVRAM |
| 62 | Set rinse drain time | 87 | Disable all sensors |
| 63 | Set air purge time | 88 | Set options |
| 64 | Set fluid purge time | 89 | --not used-- |
| 65 | Set add air time | 90 | Display inputs |
| 66 | Set partial rinse time | 91 | Display cycle count |
| 67 | Set partial rinse drain time | 92 | --not used-- |
| 68 | Set recirculation rinse time | 93 | Display temps |
| 69 | Set automatic disinfect hold time | 94 | Test sensors |
| 70 | --not used-- | 95 | Test sheath tester |
| 71 | Set maximum disinfectant cycle count | 96 | --not used-- |
| 72 | Reset programmes | 97 | --not used-- |
| 73 | Clear disinfectant counter | 98 | --not used-- |
| 74 | Set maximum reservoir temp | 99 | --not used-- |
| 75 | Set minimum basin temp | 100 | --not used-- |
| | | | |
| | | | |
| | | | |